

1. Installare il mixer, la piletta e sifone, sostituire il canotto del sifone con il flex in dotazione nella scatola, posizionare la protezione adesiva Zig-Zag seguendo le istruzioni riportate nella confezione. **ATTENZIONE:** per non scheggiare il lavabo è consigliabile appoggiarlo su un foglio di cartone durante la fase di montaggio.

Flex in dotazione nella scatola  
Flex included in the box



2. Avvicinare il lavabo a muro e collegare gli allacci idrici, a questo punto spingere il lavabo alla parete, facendo attenzione a non lesionare le adduzioni idriche.

3. Mettere del silicone sotto la base del lavabo e sigillare tutto il perimetro.

1. Install the mixer, drain pipe and siphon, replace the draining tube of siphon with flex included in the box. Position the adhesive antinoise protection "Zig-Zag" following the instructions shown on the packing. **ATTENTION:** in order to avoid to chip the wash basin, put the same on cartoon sheet.

2. Bring the wash basin to the wall and connect the water connection, then push the wash basin to the wall, makes attention to the water adduction.

3. Put silikon under the wash basin base and seal all the perimeter.

